

New Product News


ø22, ø30 Command Switches Equipped with Synchro Safe Contact

Emergency Stop Pushbutton Switches AR22VQR/VQL, VPR, AR30VPR/VPL

Full Specification of Emergency Stop Pushbutton Switches Equipped with Safety Function




- Enhanced safety
- New safety function: Synchro safety contact
 Just in case the Contact unit is removed from the operator, the switch is safe because the main NC contact opens (OFF).



Side indicator is adopted by default (except for AR30V)

The operating condition can be confirmed with the side indicator, and this helps prevent any accident being caused by a misunderstanding.



Support for Padlock (except for AR22V)

To avoid a restart due to careless reset of a pushbutton switch in case of emergency stop, make use of Padlock or HASP.




The total mass should be 1500 g or less. For information on applicable Padlock and HASP, refer to the final page.

Integrated frame (bezel) for the protrusion

Since the protrusion is integrated with the frame (bezel), there is no need to acquire it separately as an accessory. Enhanced visibility by adopting white arrow on all models.
 Also, the flange (yellow) has become bigger, so it is easy to confirm background yellow without the nameplate. (except for AR30)





- Safety trigger-action mechanism that prevents the contacts from operating until the switch is locked, even if people or objects accidentally come into contact with the switch. (compliant with ISO13850/EN418)
- Direct opening mechanism for NC contacts to ensure that the contacts can be opened even in the unlikely event that they become fused. (compliant with EN60947-5-1/JIS C 8201-5-1, Appendix K)
- Support by default for the degree of protection of operator: IP65 and the degree of protection of terminal section: IP2X (compliant with EN60204-1/JIS B 9960-1).
- Certified with UL/CSA standard and TÜV EN standard, and acquired China Compulsory Certification (CCC).
 CE mark is attached.
- UL category code NISD (EMERGENCY STOP DEVICE) under application



Enhanced operability

Enhanced release performance of contact unit

One Touch mounting. The wire is not twisted at the time of attaching and detaching the unit.





Only the release cover is turned around, and the contact is not turned around.

Reduce panel-mounting depth, connectable to up to six contacts.

"2NO+4NC" contacts (an emergency stop) enables you to construct two kinds of mechanical safety circuits (2NC: redundancy).



Enhanced routing

Since the layout of each contact is fixed regardless of the number of contacts, any miswiring can be prevented.



M3.5 is adopted for the
terminal screw diameter. It is
possible to unify it with other
inner devices.

Contact arrange- ment	Non- illuminated type	Illuminated type	Illuminated type (interlocked with lamp circuit)
1NC to 4NC			
1NO 1NC to 4NC			
2NO 1NC to 4NC		Red square me terminal "NC" Green square n terminal Blue square me terminal "NO"	neans a lamp

- Pull-reset or turn-reset is available for the reset method (turn-reset only for AR30V type).
- The illumination can be interlocked with the lamp circuit.
- Adapter dedicated for ø30 mounting hole (except for AR30V)

■ Terminal arrangement

Emergency stop pushbutton switches	Emergency stop illuminated pushbutton switches	Emergency stop illuminated pushbutton switches (interlocked with a lamp circuit)
TOP (A) 24 22 21 23 Right 13 11 12 14	TOP (A) D Right 13 11 12 14	TOP (A) 22 21 a

Specifications (indoor use)

Item		Performance		
Rated insulation voltag	e Ui	250 V AC/DC		
Durability	Mechanical	250,000 operations		
	Electrical	100,000 operations (AC-12, DC-13, DC-12)		
Operating cycles per h	our	900 operations/hour (On-load factor: 40%)		
Withstand voltage		Between live section and grounding: 2,000V AC, 1 minute		
		Between opposite polarity live sections: 2,000V AC, 1 minute		
Insulation resistance		Between live section and grounding: 100MΩ or more (500V DC megger)		
		Between opposite polarity live sections: 100MΩ or more (500V DC megger)		
Rated impulse withstand voltage Uimp		2.5 kV		
Conditional short-circuit current		1000 A		
Short-circuit protective device		gG10A (IEC60269 fuse)		
Pollution degree		3 (panel inside: 2)		
Vibration		Malfunction: maximum double amplitude: 0.7 mm (maximum: 50 m/s²), frequency: 10 to 500 Hz		
		Durability: maximum double amplitude: 0.7 mm (maximum: 50 m/s²), frequency: 10 to 500 Hz 1		
Shock		Malfunction: 150 m/s ²		
		Durability: 1000 m/s² ¹²		
Operational ambient te	mperature	Non illuminated type: -20 to +60°C, illuminated type: -20 to +50°C (no icing or no condensation)		
Storage temperature		-40 to +80°C (no icing or no condensation)		
Relative humidity		45 to 85%RH (-5 to +40°C) (no icing or no condensation)		
Degree of protection of	f operator (displaying) section	IP65 (dust-proof, water jet proof): IEC 60529		
Degree of protection of	f terminal section	IP2X (when wired)		
Connectable wire		Stranded wire: up to 1.25 mm², 24 to 16 AWG-CU		
		Solid wire: up to ø1.2 mm, 24 to 16 AWG-CU		

^{1:} The feature is decided based on the test condition for EN60947-5-5 (1998).
2: Except when the switch is mounted upside down.

Contact ratings

TÜV (EN60947-5-1), CCC (GB14048.5), and JIS C 8201-5-1

Conventional free air thermal	Rated operational voltage	Rated operational current le				
current	Ue	AC	AC			
(rated thermal current) Ith		AC-15 (Inductive load)	AC-12 (Resistive load)	DC-13 (Inductive load)	DC-12 (Resistive load)	
5 A	24 V	-	_	1.0 A	2.0 A	
	120 V	3.0 A	5.0 A	-	-	
	125 V	_	-	0.22 A	0.4 A	
	240 V	1.5 A	3.0 A	0.1 A	0.2 A	

UL/CSA standards

• AC (cosø = 0.35)

Contact rating	Conventional free air thermal	120 V		240 V	
Code	current (rated thermal current)	Making current	Breaking current	Making current	Breaking current
B300	5 A	30 A	3 A	15 A	1.5 A

• DC (T_{0.95} = 6P)

Contact rating	Conventional free air thermal	Making current & breakir	ng current
Code	current (rated thermal current)	125 V	250 V
R300	1 A	0.22 A	0.11 A

Contact reliability

FUJI has confirmed that the product can be used in 1mA circuit conditions at 5V AC or DC.

The operable range, however, may vary depending on the operational ambient conditions and type of load.

Lamp rating and current consumption

Type of lamp	Luminous color	Operational lamp voltage	Current consumption
LED lamp	Red	24 V AC/DC	7.5 mA AC, 7.5 mA DC

Note: The LED lamp of these products cannot be replaced.

Types

ø22 command switches

• Emergency stop pushbutton switches

Operator	Appearance	Contact arrangement ⁻¹	Туре	Button color
Push-lock, turn-reset	AR22VQR	1NC	AR22VQR-01R	Red [R]
Mushroom head	ead NEW	1NO+1NC	AR22VQR-11R	1
(ø40)		2NC	AR22VQR-02R	
		1NO+2NC	AR22VQR-12R	
		1NO+3NC	AR22VQR-13R	
		4NC	AR22VQR-04R	
		2NO+4NC	AR22VQR-24R	
Push-lock, turn-reset	AR22VPR	1NC	AR22VPR-01R	
Giant Mushroom head	ushroom head	1NO+1NC	AR22VPR-11R	
(ø65)		2NC	AR22VPR-02R	
		1NO+2NC	AR22VPR-12R	
		1NO+3NC	AR22VPR-13R	
		4NC	AR22VPR-04R	
		2NO+4NC	AR22VPR-24R	

^{1:} Contacts other than those in the table above are also available. 3NC [03], 2NO+1NC [21], 1NO+4NC [14], 2NO+2NC [22], 2NO+3NC [23]

• Emergency stop illuminated pushbutton switches

Operator	Appearance	Operational lamp voltage/ lamp type	Contact arrangement ⁻²	Туре	Button color
Push-lock, turn-reset	AR22VQL	24 V AC/DC	1NC	AR22VQL-01E3R	Red [R]
Mushroom head (ø40)	L	LED lamp	1NO+1NC	AR22VQL-11E3R	
	NEW		2NC	AR22VQL-02E3R	
	National		1NO+2NC	AR22VQL-12E3R	
			1NO+3NC	AR22VQL-13E3R	
			4NC	AR22VQL-04E3R	
			1NO+4NC	AR22VQL-14E3R	
		24 V AC/DC	1NC	AR22VQL-01EAR	
		LED lamp	1NO+1NC	AR22VQL-11EAR	
		Interlocked with lamp circuit	2NC	AR22VQL-02EAR	
			1NO+2NC	AR22VQL-12EAR	
			1NO+3NC	AR22VQL-13EAR	1
			4NC	AR22VQL-04EAR	
			1NO+4NC	AR22VQL-14EAR	

²: Contacts other than those in the table above are also available. 3NC [03]

ø30 command switches

• Emergency stop pushbutton switches

Operator	Appearance	Contact arrangement ^{*1}	Туре	Button color
Push-lock, turn-reset	AR30VPR	1NC	AR30VPR-01R	Red [R]
Mushroom head (ø44)	NEW	1NO+1NC	AR30VPR-11R	
		2NC	AR30VPR-02R	
Support for Padlock		1NO+2NC	AR30VPR-12R	
		1NO+3NC	AR30VPR-13R	
		4NC	AR30VPR-04R	
		2NO+4NC	AR30VPR-24R	

[&]quot;: Contacts other than those in the table above are also available. 3NC [03], 2NO+1NC [21], 1NO+4NC [14], 2NO+2NC [22], 2NO+3NC [23]


• Emergency stop illuminated pushbutton switches

Operator	Appearance	Operational lamp voltage/ lamp type	Contact arrangement ²	Туре	Button color
Push-lock, turn-reset	AR30VPL	24 V AC/DC	1NC	AR30VPL-01E3R	Red [R]
Mushroom head (ø44)		LED lamp	1NO+1NC	AR30VPL-11E3R	
	NEW		2NC	AR30VPL-02E3R	
Support for Padlock			1NO+2NC	AR30VPL-12E3R	
			1NO+3NC	AR30VPL-13E3R	
	9		4NC	AR30VPL-04E3R	
			1NO+4NC	AR30VPL-14E3R	
		24 V AC/DC	1NC	AR30VPL-01EAR	
		LED lamp	1NO+1NC	AR30VPL-11EAR	
		Interlocked with lamp circuit	2NC	AR30VPL-02EAR	
			1NO+2NC	AR30VPL-12EAR	
			1NO+3NC	AR30VPL-13EAR	
			4NC	AR30VPL-04EAR	
			1NO+4NC	AR30VPL-14EAR	


^{*2}: Contacts other than those in the table above are also available. 3NC [03]

■ Dimensions, mm


AR22VQR




AR22VQL



AR22VPR



AR30VPR / VPL



Accessories


Description	Туре			Dimensions
Wrench	Type Used with AR9A701 AR22VQR, VQL, VPR AHX536 AR30VPR, VPL Application: This allows you to tighten the tightening ring when mounting the		AR9A701: ø28 mm × 60 mm AHX536 : ø32 mm × 76 mm	
Legend plate	Type AR9P722-(1)(2)	Used with AR22VQR, VQ		[Unit: mm] Ø60 *1
00	AR9P723-(1)(2) AR9P724-(1)(2) Note 1: The values of code (1) and (2) above represent the Legend below to be printed on the Legend plate		ent the Legend	WERGENCY.
	Type Blank EMERGENCY STOP Note 2: These Legend plate a Note 3: The color of the Leger			Thickness: 0.35
AR22VQ□, VPR ø30 mounting adapter	is black. Type AR9Y958 Application: • This adapter allows you to mount the switch on a panel of ø30.5mm cutout in combination with the operator of AR22VQII and VPR (made of plastics, with ring packing and tightening nut). • The applicable panel thickness is 1 to 4.5 mm.			**2: AR9P724: ø31 [Unit: mm] ø30 mounting adapter ø30 packing ø30 tightening nut ø45 ø42.4 ø30.3 ø30.5 ø30.

Control box dedicated for emergency stop pushbutton switch

Features

- Control box for mounting the emergency stop pushbutton switch AR22VQR/VQL, VPR.
- It is easy to mount or add this box to the desired places away from the operating panel.
- Degree of protection: IP65 (when using applicable connector)
- Double-insulation structure without the need for an earth wire. (compliant with IEC536 class II)
- The knockout holes open at the top, bottom, and back.
- The emergency stop Legend plate (AR9P722) can be mounted.







Applicable connector

- Knockout holes at the top and bottom: M20, Pg13.5, or G1/2
 Recommended connector: MG20 series, MS13.5, MS-M20 x 1.5, manufactured by Hagitec inc.
- Knockout holes at the back: M14 or G1/4
 Recommended connector: SCL-B6A manufactured by Hagitec inc.

Panel cutout [mm]





Applicable panel thickness

The applicable panel thickness is 1 to 6mm. However, the thickness of the applicable panel to which ø30 switches having their mounting adapters are mounted should be 1 to 4.5mm.


If a legend plate is used, the panel should be made thinner by subtracting the thickness of that component.

Note: If a legend plate or such kind of one is used for between the switch and the fitting surface of the panel, the thickness of the legend panel should be 1.6mm or less. If the thickness exceeds the value of 1.6mm, it may prevent the fixing function of the switch.

Mounting the switch

Removing the operator from the contact unit

① Pull down the release cover of the contact unit, ② turn it counter clock wise in 15 degrees, ③ at the position pull the contact unit, after that, the contact unit can be removed from the operator.



- Caution at the removing process of the contact unit from the operator
- (1) When the contact unit is removed from the operator, at the process, "NO" contact of the unit is turned into "ON" position.
- (2) At the process when the contact unit is removed from the operator, don't give excessive force to the unit. It may cause the switch to break or to go into maloperation.
- (3) During the removing work of the contact unit from the operator, not depending on the operation position of the operator, temporarily the NC contact becomes at conductive state (At the time, the NO contact is at open state).


Mounting the operator on the panel

Remove the tightening nut and washer from the packaged state of the operator, checking the packing whether it is placed properly on to the fitting surface of the front side of the panel, insert the operator keeping whose ▼ mark at the top position into the installation hole of the panel. The operator penetrates the panel through the installation hole to the rear

The operator penetrates the panel through the installation hole to the rear side of the panel. It is fixed at the rear side of the panel with the tightening nut turned by the tightening wrench.

- Note 1 : The proper tightening torque is 1.0 to 1.5N·m for AR22, and 1.5 to 2.5N·m for AR30.
- Note 2: The tightening nut has two faces, convex and concave. Face the concave side of it to the panel when it tightens up the operator at the rear side of the panel. If it is used in the opposite face, the operator will not be fixed properly there.
- Note 3 : Check the tightening nut regularly whether it tightens the operator properly.

 If it seems that tightening is not sufficient, do not forget to tighten the screw increasingly.
- Note 4 : Do not use pliers or other improper tools to tighten the nut, and do not tighten it excessively, or the nut may be damaged or the switch may malfunction.




Mounting the contact unit

Meet the mark ▲ on the contact unit to the same mark ▼ on the operator, insert the contact unit completely into the operator until it makes a click sound. (The click sound tells that the contact unit is completely connected to the operator.)

Please consider it when you do it.

After the contact unit is set, could you check the sequence and confirm the unit whether it operates well?

- · Caution when the contact unit is set in
- (1) The "position" of the release cover of the contact unit which is being connected to the operator is different from the "position" of it of the contact unit which is removed from the operator. However, it is normal.
- (2) When the contact unit is connected to the operator, it should be connected in the specified correct way. When two units are connected, meet the apex of the triangle mark on the contact unit to the apex of the triangle mark on the operator. Connecting the units without meeting each apex of their triangle marks may cause the switch to break. If there is a switch recognized broken is remained there, it should not be used for any purpose.
- (3) During the mounting work of the contact unit from the operator, not depending on the operation position of the operator, temporarily the NC contact becomes at conductive state (At the time, the NO contact is at open state).




Others

Operation

- Do not hit or flip the button, or the button may be damaged. Be sure to
 operate the button by hand. Operate the switch manually. Don't use any tools
 such as a hummer or other tool to hit the switch for operation. It may break
 the switch.
- To unlock the switch, turn the button approximately 45° clockwise (in the direction of the arrow) or pull out the button. Do not operate or handle the button with excessive force.

Effect of receiving shock for the switch

- Effect of receiving shock for the switch ranges in the installation directions of it therefore, the installation direction should be considered for the switch to avoid effect of receiving excessive shock On the right bottom of this instruction paper, below is a figure which shows a switch installed on to the panel. When a certain value of shock is given to the switch in the direction of the arrow mark which shows the direction of gravity, the switch receives the gravitational mass effect of the button. Therefore, at the situation, the switch is easy to go into maloperation compared with other installation directions that don't give the gravitational mass effect of the button to the switch.
- Could you avoid any excess shock given to the emergency stop switch? If an excess shock is given to the switch, contact bounce may occur in the switch, it may cause a trouble in the circuit.



Contact unit


- The contact unit is not provided with dust proof, water proof or oil-tight construction. Therefore, don't allow liquid or cutting chips to pass through inside or the unprotected contact unit.
- Don't give any excessive physical load or shock to the contact unit. It may break the switch or make it in trouble to lose its ON and OFF function.
- If the release cover of the individual contact unit is turned or twisted, the contacts are switched. Please consider it when you handle it.

Storage and Usage Locations

- Be sure to use and store the product within the rated ambient temperature and humidity ranges.
- Although the product resists ordinary cutting oils and coolant oils, do not use the unit in places where special oils may be sprayed onto the product. If you are in such case, could you call us at the phone described below? We will give you a solution.
- If dusts or filings accumulate in the gap between the button and the frame, the switch may fail to operate normally.
- This switch are for indoor use. Don't use the switch for outdoor use and make sure that the product is not exposed to direct sunlight.
- Do not use the product in the places that are subject to the adverse effects of ozone or corrosive gases.


Applicable Padlock and HASP [unit: mm]

Padlock



Manufacturer	Туре	
Master Lock	6835KARFRED	

HASP



Manufacturer	Туре			
Master Lock	420, 421			
* This figure shows the dimensions of a type-420 HASP.				

The total mass of the Padlock and HASP should be 1500 g or less.

Others

Before mounting this product, wiring cables, operating this product, or maintaining and inspecting this product, make sure you read this "Instruction Manual" and use this product properly.

For Fuji Electric FA Components & Systems Co., Ltd.

5-7, Nihonbashi Odemma-cho, Chuo-ku, Tokyo, 103-0011, Japan URL http://www.fujielectric.co.jp/fcs/eng